

All you need to know - SkySentry™

SkySentry™ is a simple and effective system that prevents unauthorised use, help reduce costs, increase productivity and improve safety

- Unique pin codes and/or smartID cards ensure only authorised and trained users operate the machines
- The device automatically secures machine when not in use
- Prevents or allows sharing of machines depending on site requirements
- Provides management data which:
 - Confirms operator use and history of use on MEWPs
 - Monitors machine activity via pre-programmed parameters
 - Shows clearer utilisation of on-site MEWPs



A step by step guide, how to use SkySentry

Before Hire

- Prior to the hire start date, advise Nationwide Platforms of the operator's IPAF card number and name
- If your operator doesn't have a smart IPAF card, Nationwide will allocate a personalised PIN per operator, this will be used to start the machine.

On-site

- Once the machine has been delivered, please make sure all the E-stops are out and the key is turned to the bottom controls.
- Swipe the Smart Card or input the provided PIN on the SkySentry keypad, followed by #
- The Skysentry unit will display the green status light to confirm code has been accepted.

Any questions or problems with the above process please contact us using the below number / email



0808 100 3609

Balfour.beatty@nationwideplatforms.co.uk