

Emergency Lowering Instructions

NiftyLift Diesel Boom Lifts

Machine Range: HR21D



If there is a machine breakdown or if the operator becomes incapacitated it may be necessary to perform an emergency rescue from the ground. Emergency rescues must be rehearsed routinely.



Warning

While every effort is made to ensure that the information provided is accurate and up to date, we are not able to guarantee the completeness and accuracy of these instructions and you should therefore not rely on them. Nationwide Platforms Ltd accepts no liability for reliance on the contents of this information sheet which has been produced as additional GUIDANCE ONLY and is not intended to replace the manufacturer's manual. You should refer to the manufacturer's manual.

You should not operate this Mobile Elevating Work Platform (MEWP) unless you are suitably trained and fully familiarised with its operation and the emergency procedures set out in the manufacturer's manual. Operating plant necessarily involves risk of injury to the person.



Before starting work consider the following:

- Will there be a second person in the vicinity of the machine to undertake a rescue if required?
- Have both the operator and rescuer been familiarised with the ground controls?
- Can the rescuer gain access to the ground controls? i.e. Ensure that the machine is not parked with the ground controls facing a wall or similar obstruction.
- Is the key in the ground control to allow the rescuer to switch power from basket to ground controls?



Before attempting to operate any boom functions:

- It is imperative that an inspection be carried out to ensure the lowering of the platform is not hindered by obstructions such as steel work, pipes, cables, etc.
- If the operator in the cage has been incapacitated ensure they will not be put in additional danger by operation of the platform. Remember that completing a rescue in 4-6 minutes may be critical.
- If unsure seek help (it may be necessary to carry out a mid air rescue).
- Carefully plan each action before starting to lower the platform.



If the platform functions are inoperative but the operator is not incapacitated or in danger in any way, follow these instructions:

- 1 Ensure the platform and ground control red emergency stops are out.
- 2 Turn the ground control key switch to the ground position.
- 3 To start the engine from cold turn the Diesel Glow/Start switch to the Glow position (counter clockwise) and hold for 3-5 seconds then turn the switch to the Start position (fully clockwise) and the engine will start.
- 4 If the engine is already warm through use turn the Diesel Glow/Start switch to the Start position (clockwise) and the engine will start.
- 5 Push and hold green power button on the base control box. Select a function and operate the appropriate hydraulic lever.



- Red Emergency Stop Button
- Engine Start Position
- Glow Plug Position
- Glow Plug/Engine Start Switch
- Ground Control Platform/ Ground Control Select Key Switch
- Green Power



Hydraulic Levers



Function Lever Direction Decal




If the engine cannot be started from the ground control position follow these instructions:

- 1 Push in the Emergency Stop Switch.
- 2 Open the ground control canopy to expose the control levers and the hand pump manifold.
- 3 Insert the pump handle into the manifold handle housing.
- 4 Follow the pictorial information on the lever decal and hold the levers in the desired position to lower the boom sections.
- 5 Simultaneously start to pump the handle until the booms are fully stowed.



Hand Pump Handle



Function Lever Direction Decal



Hydraulic Levers



Hand Pump Manifold and Pump Handle Housing



Technical advice and training courses:

If the controls do not function or you are unsure of their operation please call our Technical Support team on 0845 745 0000 option 2.

As the UK's largest training provider in our industry, we have a range of courses to help you and your operators to work efficiently and safely at height.

Contact us for full details of courses and dates.